

Component material PSE/PSS/PSW

"x" indicates stainless steel. All parts with an "-" is another material.

	PSE	PSS	PSW
Connector	-	-	X
Screw nut for connector	-	-	X
Housing	-	X	X
Torque support	-	X	X
Protection cap for connectors (optional)	-	X	X
Screw for ground connection	-	X	X
Screw nut for ground connection	-	-	X
Tooth washer for ground connection	-	-	X
Clamp ring for hollow shaft	-	-	X
Screw for clamp ring	-	-	X
Safety ring for clamp ring	-	-	X
Output hollow shaft	-	-	X
Protection cap for manual release (if available)	-	X	X
Feather key (if available)	-	-	-
Screws which you can see from the outside	-	-/X	X
Glass protection cap for address switches	-	X	X